

SW2, SW2-US Auxiliary Switch Kit for HVAC Damper Actuators MNXX20, MNXX34, MSXX10A, MSXX20A

INSTALLATION INSTRUCTIONS

<p>1</p> <p>Ø = 4 ... 000 AWG (5 ... 10 mm)</p> <p>100 Vac, 5 (3) A</p> <p>Ø = 4 ... 000 AWG (5 ... 10 mm)</p> <p>2-3/8 - 3-1/8 in. (60 - 80 mm)</p> <p>3/16 in. (5 mm)</p> <p>A</p> <p>B</p> <p>M25331</p>	<p>2</p> <p>B</p> <p>A</p> <p>M25332</p>	<p>3 (MSXX05A, MSXX10A, MSXX20A)</p> <p>M25333</p>
<p>4</p> <p>Ø = 4 ... 000 AWG (5 ... 10 mm)</p> <p>100 Vac, 5 (3) A</p> <p>Ø = 4 ... 000 AWG (5 ... 10 mm)</p> <p>2-3/8 - 3-1/8 in. (60 - 80 mm)</p> <p>3/16 in. (5 mm)</p> <p>A</p> <p>B</p> <p>M25331</p>	<p>5</p> <p>24 V + 24 V ✓</p> <p>M25335</p>	<p>6</p> <p>A</p> <p>or</p> <p>A</p> <p>B</p> <p>C</p> <p>M25336</p>
<p>7</p> <p>20 mm</p> <p>6 Nm</p> <p>A</p> <p>B</p> <p>C</p> <p>M25337</p>	<p>8</p> <p>AS1</p> <p>AS2</p> <p>A S3</p> <p>B S1</p> <p>S2</p> <p>S6</p> <p>S4</p> <p>S5</p> <p>C</p> <p>D</p> <p>45</p> <p>90</p> <p>0</p> <p>90</p> <p>0</p> <p>A</p> <p>B</p> <p>C</p> <p>D</p> <p>M25338</p>	<p>9 Setting AS1, AS2</p> <p>10-15</p> <p>M25339</p>

