

Honeywell

IMPORTANT!


Refer to this information to remove the wallplate from the thermostat. This replaces the information on page 11 (**Mount New Wallplate to Wall**) of the Installation Instructions (Form no. 69-1716).

IMPORTANT !

Veillez consulter les renseignements qui suivent pour retirer la plaque murale du thermostat. Ces renseignements remplacent ceux de la page 11 (**Installer le nouveau thermostat au mur** (Publication 69-1716F).

IMPORTANTE:

Consulte esta información para quitar la placa de pared del termostato. Esto reemplaza la información que aparece en la página 11 (**Montar nueva placa de pared a la pared**) de las Instrucciones de Instalación (Formulario número 69-1716S).



Automation and Control Solutions

Honeywell International Inc.
1985 Douglas Drive North
Golden Valley, MN 55422
yourhome.honeywell.com

® U.S. Registered Trademark
© 2005 Honeywell International Inc.
C.H. 08-05

Honeywell Limited-Honeywell Limitée
35 Dynamic Drive
Scarborough, Ontario M1V 4Z9



69-A1716EFS